

Repairing the Blue Delphi Connector Brake Wires

If needed, damaged wires can be repaired on the Delphi 15300027 Metri-Pack 280 Connector. Cut away the bad part of the wires, strip the ends and reseal in a new (or repurposed) delphi connector pack.



Be sure to zip tie the bundle in the locations shown below. This will provide the necessary support.

