



Scrub Head Bumper Skirt Kit

Models: T300, T300e, T350, T3, T3e, T5, T5e, Speed Scrub 300 & Speed Scrub (SS3, SS5)



INSTALLATION INSTRUCTIONS:

Tool Required: 7 mm Socket Wrench

1. Park machine on level surface, raise scrub head and remove key.
2. Loosen two screws on one side of adjustment strap.
3. Install bumper skirt on scrub head.
4. **IMPORTANT:** Adjust bumper skirt until tight enough to stay on scrub head, but loose enough to float up and down.
5. Tighten all four screws once properly adjusted.

