


## KNOW YOUR MACHINE

- 1 Solution Switch
- 2A Accessory Solution Hose (16XP, 18FLX)
- 2B Accessory Solution Port (16ST / 18ST only)
- 3 Recovery Hose
- 4 Recovery Tank Dome Lid
- 5 Recovery Tank
- 6 Solution Tank
- 7 Pin Release for vacuum shoe
- 8 Vacuum Shoe
- 9 Nozzle Selector Knob (16XP, 18FLX)
  - 9A Maintenance Mode
  - 9B Restoration Mode
- 10A Power Cord (16XP, 18FLX, 18ST)
- 10B Power Cord Locking Mechanism (16XP, 18FLX, 18ST)
- 11 Pigtail Cord (Full Length Cord on 16ST, 18ST)
- 12 Recovery Tank Drain Hose
- 13 Solution Screen
- 14 Automatic Float Shut-Off



# KNOW YOUR MACHINE (CONTINUED)

- 15 Solution Drain Hose / Level Indicator
- 16 Handle Release Pedal
- 17 Brush Pressure Control Knob
- 18 Recovery Hose Connection (16XP, 18FLX)
- 19A Handle Assembly 16
- 19B Handle Assembly 18
- 20 Hand Tool Assembly (16XP, 18FLX)
- 21A Handle Angle Adjustment Knobs
- 21B Handle Position Adjustment Lever
- 22 Brush Motor Circuit Breaker
- 23 Power & Extract / Accessory Switch
- 24 Solution Switch (Constant or Intermittent)

