

Circuit Breaker Check

There are two circuit breakers under the seat. The main push-button breaker and the “Brain 20 Amp rocker switch breaker”. The Brain 20A breaker provides power to the brain autonomy components. Check this breaker if the scrubber turns on but the User Interface is dark.

Lift seat. Near the front of seat, locate red power cable.

To either side of the red power cable are the push-button breaker, and the Brain 20A rocker switch breaker



Tripped Brain Breaker.

Note white switch visible.

Disconnect the power main, and push the top of the breaker to reset it



Breaker shown in operable state,

The rocker switch is flush and the top white part of the breaker is not visible

