


Adjusting the Tension of the Scrub Brush

Pull the scrub brush straight downward to remove it from the scrubber.



Use a Phillips screwdriver to loosen the indicated screw



Slide the locking spring upward and free of the brush mount.



Squeeze the locking spring to increase inward tension. Reinstall.

