



Machines

Machine

TASKI swingo 350B – 1255B

Subassembly


Rear cover

Battery plug to be disconnected during storage and charging

Due to safety reasons it is necessary to disconnect the battery plug from the machine during storage and charging. The machine is unsupervised during these two states and must be deenrgized mandatorily.

In order that the operator does not forget about it, a sticker which is showing the plug and referring to the user manual has been placed above the disconnecting plug. In the manual it is stressed out again in which situation the machine must be de-energized mandatorily.





Please advise our customers to follow this instruction.

Other machines without cutoff relay (TASKI swingo 455B - 1255B) will also be equipped with this sticker in the near future. No newsletter will be released for the other machine types.

Description	Material number	Remarks
Label disconnecting plug	4132863 (17422-26)	New spare part number



ΔSI

Service Information

- Check parts on stock
- □ Proactive exchange recommended
- Modification is backwards compatible
- Update/modify machines in the field
- □ Dispose/recycle defective parts
- ✓ Others

- Return defektive parts to Münchwilen
- ☑ NO proactive exchange recommended
- □ Modification is NOT backwards compatible
- Entitled to warranty
- Parts are available ex stock Münchwilen

Please place the sticker during the next service.

Production

TASKI swingo 350B

as of machine number 17370