Spare parts list

ergodisc

165-438 & duo



Edition: V5.02/2023


Table of contents

TASKI ergodisc_5 3
- Main cord & cable inlet box 4
- Guide bar 12
- Drive part/1 16
- Drive part/2 20
- Dispensing unit mechnical 29
- Dispensing unit electrical 31
- Electrical diagram 230V/50Hz 34
- Electrical diagram 120V/60Hz 36

TASKI ergodisc_5

Description
Main cord & cable inlet box
Guide bar
Drive part/1
Drive part/2
Dispensing unit mechnical
Dispensing unit electrical
Electrical diagram 230V/50Hz
Electrical diagram 120V/60Hz

Main cord & cable inlet box



ergodisc /3

01

Main cord & cable inlet box

Article no.	Description	Quantity	Unit	used for
4108320	Main cord 2L SEA	1	PC	8003800 - TASKI ergodisc 200 SEV
4108320	Main cord 2L SEA	1	PC	8003840 - TASKI ergodisc 165 SEV
4108320	Main cord 2L SEA	1	PC	8003880 - TASKI ergodisc 400 SEV
4108320	Main cord 2L SEA	1	PC	8004010 - TASKI ergodisc duo SEV
4108310	Main cord 2L EURO	1	PC	8003810 - TASKI ergodisc 200 EURO
4108310	Main cord 2L EURO	1	PC	8003850 - TASKI ergodisc 165 EURO
4108310	Main cord 2L EURO	1	PC	8003890 - TASKI ergodisc 400 EURO
4108310	Main cord 2L EURO	1	PC	8004020 - TASKI ergodisc duo EURO
4108310	Main cord 2L EURO	1	PC	7521877 - TASKI ergodisc 165 EURO
4123192	Main cord 2L UK	1	PC	8004410 - TASKI ergodisc 165 KSA
	Main cord 2L CN	1	PC	7517949 - TASKI ergodisc 165 CN
	Main cord 2L CN	1	PC	7517950 - TASKI ergodisc 200 CN
	Main cord 2L CN	1	PC	7517951 - TASKI ergodisc duo CN
4108300	Main cord 2L UK	1	PC	8003780 - TASKI ergodisc 200 UK
4108300	Main cord 2L UK	1	PC	8003820 - TASKI ergodisc 165 UK
4108300	Main cord 2L UK	1	PC	8003860 - TASKI ergodisc 400 UK
4108300	Main cord 2L UK	1	PC	8003990 - TASKI ergodisc duo UK
4108300	Main cord 2L UK	1	PC	8004030 - TASKI ergodisc 238 UK
4108300	Main cord 2L UK	1	PC	8004040 - TASKI ergodisc 438 UK
4108300	Main cord 2L UK	1	PC	8005000 - TASKI ergodisc 165 JP 50Hz
4108290	Main cord 2L+P NA	1	PC	7510804 - TASKI ergodisc 200 NA

Main cord & cable inlet box

Article no.	Description	Quantity	Unit	used for
4108290	Main cord 2L+P NA	1	PC	8003790 - TASKI ergodisc 175 NA
4108290	Main cord 2L+P NA	1	PC	8003830 - TASKI ergodisc 300 NA
4108290	Main cord 2L+P NA	1	PC	8004760 - TASKI ergodisc 165 JP 60Hz
4101980	Screw for plastic KA50x20	8	PC	
4126845	Plate	1	PC	Option
4126557	Hook	1	PC	Option
4108280	Lamp 230V kpl	1	PC	220-240V
4108270	Lamp 120V kpl	1	PC	100-120V
4109680	Cover	1	PC	7510804 - TASKI ergodisc 200 NA
4109680	Cover	1	PC	8003780 - TASKI ergodisc 200 UK
4109680	Cover	1	PC	8003790 - TASKI ergodisc 175 NA
4109680	Cover	1	PC	8003820 - TASKI ergodisc 165 UK
4109680	Cover	1	PC	8003830 - TASKI ergodisc 300 NA
4109680	Cover	1	PC	8003860 - TASKI ergodisc 400 UK
4109680	Cover	1	PC	8003990 - TASKI ergodisc duo UK
4109680	Cover	1	PC	8004030 - TASKI ergodisc 238 UK
4109680	Cover	1	PC	8004040 - TASKI ergodisc 438 UK
4109680	Cover	1	PC	8004760 - TASKI ergodisc 165 JP 60Hz
4109680	Cover	1	PC	8005000 - TASKI ergodisc 165 JP 50Hz
4109690	Cover	1	PC	7517949 - TASKI ergodisc 165 CN
4109690	Cover	1	PC	7517950 - TASKI ergodisc 200 CN
4109690	Cover	1	PC	7517951 - TASKI ergodisc duo CN
4109690	Cover	1	PC	8003800 - TASKI ergodisc 200 SEV

Main cord & cable inlet box

Article no.	Description	Quantity	Unit	used for
4109690	Cover	1	PC	8003810 - TASKI ergodisc 200 EURO
4109690	Cover	1	PC	8003840 - TASKI ergodisc 165 SEV
4109690	Cover	1	PC	8003850 - TASKI ergodisc 165 EURO
4109690	Cover	1	PC	8003880 - TASKI ergodisc 400 SEV
4109690	Cover	1	PC	8003890 - TASKI ergodisc 400 EURO
4109690	Cover	1	PC	8004010 - TASKI ergodisc duo SEV
4109690	Cover	1	PC	8004020 - TASKI ergodisc duo EURO
4109690	Cover	1	PC	8004410 - TASKI ergodisc 165 KSA
4110120	Cover	1	PC	7517950 - TASKI ergodisc 200 CN
4110120	Cover	1	PC	8003780 - TASKI ergodisc 200 UK
4110120	Cover	1	PC	8003800 - TASKI ergodisc 200 SEV
4110120	Cover	1	PC	8003810 - TASKI ergodisc 200 EURO
4110120	Cover	1	PC	8004030 - TASKI ergodisc 238 UK
4110300	Plug socket 2L+P	1	PC	100-120V
4110110	Plug socket 2L	1	PC	7517949 - TASKI ergodisc 165 CN
4110110	Plug socket 2L	1	PC	7517951 - TASKI ergodisc duo CN
4110110	Plug socket 2L	1	PC	7521877 - TASKI ergodisc 165 EURO
4110110	Plug socket 2L	1	PC	8003820 - TASKI ergodisc 165 UK
4110110	Plug socket 2L	1	PC	8003840 - TASKI ergodisc 165 SEV
4110110	Plug socket 2L	1	PC	8003850 - TASKI ergodisc 165 EURO
4110110	Plug socket 2L	1	PC	8003860 - TASKI ergodisc 400 UK
4110110	Plug socket 2L	1	PC	8003880 - TASKI ergodisc 400 SEV

Main cord & cable inlet box

Article no.	Description	Quantity	Unit	used for
4110110	Plug socket 2L	1	PC	8003890 - TASKI ergodisc 400 EURO
4110110	Plug socket 2L	1	PC	8003990 - TASKI ergodisc duo UK
4110110	Plug socket 2L	1	PC	8004010 - TASKI ergodisc duo SEV
4110110	Plug socket 2L	1	PC	8004020 - TASKI ergodisc duo EURO
4110110	Plug socket 2L	1	PC	8004040 - TASKI ergodisc 438 UK
4110110	Plug socket 2L	1	PC	8004410 - TASKI ergodisc 165 KSA
4110110	Plug socket 2L	1	PC	8005000 - TASKI ergodisc 165 JP 50Hz
4107150	Gasket	1	PC	
4107300	Cover	1	PC	
4114450	Torsion spring	1	PC	
4089580	Extensible pin 2x36	1	PC	
4047410	Connection bloc 3-ways 2,5 mm²	1	PC	
4062420	Screw delta PT Torx 30x16	3	PC	
4001020	Clamp	1	PC	
4110100	Plug	1	PC	Option
4078770	Plug socket 2L	1	PC	8003780 - TASKI ergodisc 200 UK
4078770	Plug socket 2L	1	PC	8003820 - TASKI ergodisc 165 UK
4078770	Plug socket 2L	1	PC	8003860 - TASKI ergodisc 400 UK
4078770	Plug socket 2L	1	PC	8003990 - TASKI ergodisc duo UK
4078770	Plug socket 2L	1	PC	8004030 - TASKI ergodisc 238 UK
4078770	Plug socket 2L	1	PC	8004040 - TASKI ergodisc 438 UK
4078770	Plug socket 2L	1	PC	8005000 - TASKI ergodisc 165 JP 50Hz
4081620	Plug socket 2L+P	1	PC	7510804 - TASKI ergodisc 200 NA
4081620	Plug socket 2L+P	1	PC	8003790 - TASKI ergodisc

Main cord & cable inlet box


Article no.	Description	Quantity	Unit	used for
				175 NA
4081620	Plug socket 2L+P	1	PC	8003830 - TASKI ergodisc 300 NA
4081620	Plug socket 2L+P	1	PC	8004760 - TASKI ergodisc 165 JP 60Hz
4015720	Screw for plastic KA40x14	2	PC	
4015590	Screw for plastic KA35x10	4	PC	
4088150	Cover	1	PC	
4088140	Plug socket 2L+P	1	PC	7510804 - TASKI ergodisc 200 NA
4088140	Plug socket 2L+P	1	PC	8003790 - TASKI ergodisc 175 NA
4088140	Plug socket 2L+P	1	PC	8003830 - TASKI ergodisc 300 NA
4088140	Plug socket 2L+P	1	PC	8004760 - TASKI ergodisc 165 JP 60Hz
4095210	Plug socket 2L	1	PC	8003780 - TASKI ergodisc 200 UK
4095210	Plug socket 2L	1	PC	8003820 - TASKI ergodisc 165 UK
4095210	Plug socket 2L	1	PC	8003860 - TASKI ergodisc 400 UK
4095210	Plug socket 2L	1	PC	8003990 - TASKI ergodisc duo UK
4095210	Plug socket 2L	1	PC	8004030 - TASKI ergodisc 238 UK
4095210	Plug socket 2L	1	PC	8004040 - TASKI ergodisc 438 UK
4095210	Plug socket 2L	1	PC	8005000 - TASKI ergodisc 165 JP 50Hz
4079480	Screw for plastic KA35x20	1	PC	
4081460	Cable grommet	1	PC	8003780 - TASKI ergodisc 200 UK
4081460	Cable grommet	1	PC	8003820 - TASKI ergodisc 165 UK
4081460	Cable grommet	1	PC	8003860 - TASKI ergodisc 400 UK
4081460	Cable grommet	1	PC	8003990 - TASKI ergodisc duo UK
4081460	Cable grommet	1	PC	8004030 - TASKI ergodisc 238 UK

Main cord & cable inlet box

Article no.	Description	Quantity	Unit	used for
4081460	Cable grommet	1	PC	8004040 - TASKI ergodisc 438 UK
4081460	Cable grommet	1	PC	8005000 - TASKI ergodisc 165 JP 50Hz
4089210	Cable grommet	1	PC	7510804 - TASKI ergodisc 200 NA
4089210	Cable grommet	1	PC	7517949 - TASKI ergodisc 165 CN
4089210	Cable grommet	1	PC	7517950 - TASKI ergodisc 200 CN
4089210	Cable grommet	1	PC	7517951 - TASKI ergodisc duo CN
4089210	Cable grommet	1	PC	7521877 - TASKI ergodisc 165 EURO
4089210	Cable grommet	1	PC	8003790 - TASKI ergodisc 175 NA
4089210	Cable grommet	1	PC	8003800 - TASKI ergodisc 200 SEV
4089210	Cable grommet	1	PC	8003810 - TASKI ergodisc 200 EURO
4089210	Cable grommet	1	PC	8003830 - TASKI ergodisc 300 NA
4089210	Cable grommet	1	PC	8003840 - TASKI ergodisc 165 SEV
4089210	Cable grommet	1	PC	8003850 - TASKI ergodisc 165 EURO
4089210	Cable grommet	1	PC	8003880 - TASKI ergodisc 400 SEV
4089210	Cable grommet	1	PC	8003890 - TASKI ergodisc 400 EURO
4089210	Cable grommet	1	PC	8004010 - TASKI ergodisc duo SEV
4089210	Cable grommet	1	PC	8004020 - TASKI ergodisc duo EURO
4089210	Cable grommet	1	PC	8004410 - TASKI ergodisc 165 KSA
4089210	Cable grommet	1	PC	8004760 - TASKI ergodisc 165 JP 60Hz
4108260	Pressure switch	1	PC	7510804 - TASKI ergodisc 200 NA
4108260	Pressure switch	1	PC	7517949 - TASKI ergodisc 165 CN
4108260	Pressure switch	1	PC	7517951 - TASKI ergodisc

Main cord & cable inlet box

Article no.	Description	Quantity	Unit	used for
				duo CN
4108260	Pressure switch	1	PC	7521877 - TASKI ergodisc 165 EURO
4108260	Pressure switch	1	PC	8003790 - TASKI ergodisc 175 NA
4108260	Pressure switch	1	PC	8003830 - TASKI ergodisc 300 NA
4108260	Pressure switch	1	PC	8003840 - TASKI ergodisc 165 SEV
4108260	Pressure switch	1	PC	8003850 - TASKI ergodisc 165 EURO
4108260	Pressure switch	1	PC	8003880 - TASKI ergodisc 400 SEV
4108260	Pressure switch	1	PC	8003890 - TASKI ergodisc 400 EURO
4108260	Pressure switch	1	PC	8004010 - TASKI ergodisc duo SEV
4108260	Pressure switch	1	PC	8004020 - TASKI ergodisc duo EURO
4108260	Pressure switch	1	PC	8004410 - TASKI ergodisc 165 KSA
4108260	Pressure switch	1	PC	8004760 - TASKI ergodisc 165 JP 60Hz
4126558	Torsion spring	1	PC	Option
4116440	Label ergonomics	1	PC	



ergodisc /2.2

02

Guide bar


Article no.	Description	Quantity	Unit	used for
4101980	Screw for plastic KA50x20	22	PC	
4108670	Handle housing	1	PC	
4109830	Lever	1	PC	
4109820	Lever	1	PC	
4109810	Push button	1	PC	
4118190	Connecting cable 4L	1	PC	7517949 - TASKI ergodisc 165 CN
4118190	Connecting cable 4L	1	PC	7517951 - TASKI ergodisc duo CN
4118190	Connecting cable 4L	1	PC	7521877 - TASKI ergodisc 165 EURO
4118190	Connecting cable 4L	1	PC	8003840 - TASKI ergodisc 165 SEV
4118190	Connecting cable 4L	1	PC	8003850 - TASKI ergodisc 165 EURO
4118190	Connecting cable 4L	1	PC	8003880 - TASKI ergodisc 400 SEV
4118190	Connecting cable 4L	1	PC	8003890 - TASKI ergodisc 400 EURO
4118190	Connecting cable 4L	1	PC	8004010 - TASKI ergodisc duo SEV
4118190	Connecting cable 4L	1	PC	8004020 - TASKI ergodisc duo EURO
4118190	Connecting cable 4L	1	PC	8004410 - TASKI ergodisc 165 KSA
4114440	Connecting cable 4L+P	1	PC	7510804 - TASKI ergodisc 200 NA
4114440	Connecting cable 4L+P	1	PC	8003790 - TASKI ergodisc 175 NA
4114440	Connecting cable 4L+P	1	PC	8003830 - TASKI ergodisc 300 NA
4114440	Connecting cable 4L+P	1	PC	8004760 - TASKI ergodisc 165 JP 60Hz
4116830	Connection cable 2L	1	PC	7517950 - TASKI ergodisc 200 CN
4116830	Connection cable 2L	1	PC	8003780 - TASKI ergodisc 200 UK
4116830	Connection cable 2L	1	PC	8003800 - TASKI ergodisc 200 SEV
4116830	Connection cable 2L	1	PC	8003810 - TASKI ergodisc 200 EURO

Guide bar

Article no.	Description	Quantity	Unit	used for
4116830	Connection cable 2L	1	PC	8003820 - TASKI ergodisc 165 UK
4116830	Connection cable 2L	1	PC	8003860 - TASKI ergodisc 400 UK
4116830	Connection cable 2L	1	PC	8003990 - TASKI ergodisc duo UK
4116830	Connection cable 2L	1	PC	8004030 - TASKI ergodisc 238 UK
4116830	Connection cable 2L	1	PC	8004040 - TASKI ergodisc 438 UK
4116830	Connection cable 2L	1	PC	8005000 - TASKI ergodisc 165 JP 50Hz
4109800	Profile pipe	1	PC	
4109790	Protection shield	1	PC	
4015720	Screw for plastic KA40x14	7	PC	
4093840	Washer 5,3/15x1,2	1	PC	
4109580	Cable hook	1	PC	
4001020	Clamp	1	PC	
4109840	Holder	1	PC	
4121580	Pressure spring	1	PC	
4109850	Guide	1	PC	
4108350	Cover	1	PC	
4109970	Flange bolt	4	PC	
4031090	Washer 8,4/20x1,2	4	PC	
4108340	Buffer	8	PC	
4092870	Self-locking nut M6	12	PC	
4123656	Socket head cap screw M6x45/24	4	PC	
4007470	Washer 6,4/12x1,6	4	PC	
4042630	Socket head cap screw M8x40	3	PC	
4109960	Profile pipe	1	PC	
4059860	Ball 8,5	1	PC	
4109950	Lever	1	PC	
4027910	Elastic cord	1	PC	
4025940	Hook	1	PC	
4109940	Lever	1	PC	
4108680	Handle housing	1	PC	

Guide bar

Article no.	Description	Quantity	Unit	used for
4109930	Rolle 20,7	1	PC	
4108230	Protective motor switch 12A	1	PC	220-240V
4108240	Protective motor switch 16A	1	PC	100-120V
4109920	Bowden cable	1	PC	
4109860	Pressure spring	1	PC	
4109570	Bolt	1	PC	
4109560	Plate	1	PC	
4109730	Locking bolt with teeth	1	PC	
4019790	Washer 6,4/20x1,5	4	PC	
4109720	Toothed wheel T54	1	PC	
4007340	Self-locking nut M8	3	PC	
4109760	Support	1	PC	
4109780	Bush spec	2	PC	
4109910	O-ring 55x3	2	PC	
4109740	Articulation	1	PC	
4108380	Cover	1	PC	
4109770	Support	1	PC	
4122268	Gasket	2	PC	
4001020	Clamp	1	PC	
4062420	Screw delta PT Torx 30x16	2	PC	
4118240	Lubricant OKS 265 1000gr	0	PC	



ergodisc /4.1

03

Drive part/1


Article no.	Description	Quantity	Unit	used for
4109590	Cover	1	PC	
4109600	Cover	1	PC	Duo Speed
4082610	Screw for plastic KA50x16	4	PC	
4109490	Housing	1	PC	
4110030	Plug 15	2	PC	
4117100	Nippel set	1	PC	
4008950	O-ring 10x2	2	PC	
4116970	Sealing profile	0,25	M	
4015720	Screw for plastic KA40x14	4	PC	
4122439	Nippel spec	1	PC	
4109370	Screw for plastic KA50x25	6	PC	
4109900	Support	1	PC	
4109990	Screw delta PT Torx 60x25	10	PC	
4109990	Screw delta PT Torx 60x25	6	PC	Ø 43
4007400	Washer 8,4/16x1,6	3	PC	
4042650	Socket head cap screw M8x25	3	PC	
4108250	Poly-V-belt 23 PH 820	1	PC	
4108450	Flat belt pulley 192	1	PC	
4108440	Flat belt pulley 158,4	1	PC	8003830 - TASKI ergodisc 300 NA
4108440	Flat belt pulley 158,4	1	PC	8003860 - TASKI ergodisc 400 UK
4108440	Flat belt pulley 158,4	1	PC	8003880 - TASKI ergodisc 400 SEV
4108440	Flat belt pulley 158,4	1	PC	8003890 - TASKI ergodisc 400 EURO
4108440	Flat belt pulley 158,4	1	PC	8004040 - TASKI ergodisc 438 UK
4008690	Retaining ring 25 A	1	PC	
4122440	Gasket	1	PC	
4130053	Screw for plastic KA50x30	3	PC	
4110060	Grommet 12,5	4	PC	
4110080	Bush spec	1	PC	8004030 - TASKI ergodisc 238 UK
4110080	Bush spec	1	PC	8004040 - TASKI ergodisc

Drive part/1

Article no.	Description	Quantity	Unit	used for
				438 UK
4122441	Flanged bush spec	1	PC	
4109630	Weight	1	PC	7510804 - TASKI ergodisc 200 NA
4109630	Weight	1	PC	7517949 - TASKI ergodisc 165 CN
4109630	Weight	1	PC	7517951 - TASKI ergodisc duo CN
4109630	Weight	1	PC	7521877 - TASKI ergodisc 165 EURO
4109630	Weight	1	PC	8003790 - TASKI ergodisc 175 NA
4109630	Weight	1	PC	8003820 - TASKI ergodisc 165 UK
4109630	Weight	1	PC	8003840 - TASKI ergodisc 165 SEV
4109630	Weight	1	PC	8003850 - TASKI ergodisc 165 EURO
4109630	Weight	1	PC	8003990 - TASKI ergodisc duo UK
4109630	Weight	1	PC	8004010 - TASKI ergodisc duo SEV
4109630	Weight	1	PC	8004020 - TASKI ergodisc duo EURO
4109630	Weight	1	PC	8004410 - TASKI ergodisc 165 KSA
4109630	Weight	1	PC	8004760 - TASKI ergodisc 165 JP 60Hz
4109630	Weight	1	PC	8005000 - TASKI ergodisc 165 JP 50Hz
4031090	Washer 8,4/20x1,2	1	PC	
4088430	Star knob M6	1	PC	
4109650	Flange bolt	1	PC	
4109670	Plate	1	PC	
4082610	Screw for plastic KA50x16	3	PC	
4109660	Flange	1	PC	
4017370	Adhesive locking middle	1	PC	
4122438	Flange	1	PC	
4109190	Brush coupling	1	PC	
4037840	Grommet 13,9	1	PC	

Drive part/1

Article no.	Description	Quantity	Unit	used for
4110020	Cover	2	PC	
4121973	Raised cheese hd.screw M6x35	3	PC	
4007550	Washer 6,4/16x0,8	3	PC	
4127045	Brush housing	1	PC	Ø 38
4126760	Brush housing	1	PC	Ø 43
4127043	Brush housing	1	PC	Ø 50
4122574	Weight	1	PC	S04
4122574	Weight	1	PC	S05, DUO
4109540	Weight	1	PC	8004040 - TASKI ergodisc 438 UK
4109540	Weight	1	PC	8004030 - TASKI ergodisc 238 UK
4109550	Weight	1	PC	8003790 - TASKI ergodisc 175 NA
4112110	Cam commutator	1	PC	
4110320	Gasket	1	PC	
4126350	Bush 4,5/6x3	2	PC	
4035560	Counters. head screw M4x12	2	PC	
4110330	Label I/O	1	PC	
4122624	Nut M6 spec	1	PC	
4006440	Socket head cap screw M6x16	3	PC	
4122577	Flange bolt	2	PC	
4122798	Bolt	2	PC	
4123215	Gasket	1	PC	
4127001	Cover	1	PC	
4031660	Adhesive locking faint	0	PC	
4122309	Turning knob	1	PC	
4123156	Disc	1	PC	
4082610	Screw for plastic KA50x16	3	PC	
4039680	Lubricant synsetral 53B 1000gr	1	PC	



ergodisc /4.1

04

Drive part/2

Article no.	Description	Quantity	Unit	used for
4133916	Start capacitor 80µF	1	PC	7517949 - TASKI ergodisc 165 CN
4133916	Start capacitor 80µF	1	PC	7517950 - TASKI ergodisc 200 CN
4133916	Start capacitor 80µF	1	PC	7517951 - TASKI ergodisc duo CN
4133916	Start capacitor 80µF	1	PC	7521877 - TASKI ergodisc 165 EURO
4133916	Start capacitor 80µF	1	PC	8003780 - TASKI ergodisc 200 UK
4133916	Start capacitor 80µF	1	PC	8003800 - TASKI ergodisc 200 SEV
4133916	Start capacitor 80µF	1	PC	8003810 - TASKI ergodisc 200 EURO
4133916	Start capacitor 80µF	1	PC	8003820 - TASKI ergodisc 165 UK
4133916	Start capacitor 80µF	1	PC	8003840 - TASKI ergodisc 165 SEV
4133916	Start capacitor 80µF	1	PC	8003850 - TASKI ergodisc 165 EURO
4133916	Start capacitor 80µF	1	PC	8003990 - TASKI ergodisc duo UK
4133916	Start capacitor 80µF	1	PC	8004010 - TASKI ergodisc duo SEV
4133916	Start capacitor 80µF	1	PC	8004020 - TASKI ergodisc duo EURO
4133916	Start capacitor 80µF	1	PC	8004030 - TASKI ergodisc 238 UK
4133916	Start capacitor 80µF	1	PC	8004410 - TASKI ergodisc 165 KSA
4108160	Start capacitor 100µF	1	PC	8003860 - TASKI ergodisc 400 UK
4108160	Start capacitor 100µF	1	PC	8003880 - TASKI ergodisc 400 SEV
4108160	Start capacitor 100µF	1	PC	8003890 - TASKI ergodisc 400 EURO
4108160	Start capacitor 100µF	1	PC	8004040 - TASKI ergodisc 438 UK
4108170	Start capacitor 400µF	1	PC	8004760 - TASKI ergodisc 165 JP 60Hz
4118050	Start capacitor 300µF	1	PC	7510804 - TASKI ergodisc 200 NA

Drive part/2

Article no.	Description	Quantity	Unit	used for
4118050	Start capacitor 300µF	1	PC	8003790 - TASKI ergodisc 175 NA
4118050	Start capacitor 300µF	1	PC	8003830 - TASKI ergodisc 300 NA
4118050	Start capacitor 300µF	1	PC	8005000 - TASKI ergodisc 165 JP 50Hz
4108150	Run capacitor 25µF	1	PC	7510804 - TASKI ergodisc 200 NA
4108150	Run capacitor 25µF	1	PC	8003790 - TASKI ergodisc 175 NA
4108150	Run capacitor 25µF	1	PC	8003830 - TASKI ergodisc 300 NA
4108150	Run capacitor 25µF	1	PC	8004760 - TASKI ergodisc 165 JP 60Hz
4108200	Run capacitor 32µF	1	PC	7517949 - TASKI ergodisc 165 CN
4108200	Run capacitor 32µF	1	PC	7517951 - TASKI ergodisc duo CN
4108200	Run capacitor 32µF	1	PC	7521877 - TASKI ergodisc 165 EURO
4108200	Run capacitor 32µF	1	PC	8003820 - TASKI ergodisc 165 UK
4108200	Run capacitor 32µF	1	PC	8003840 - TASKI ergodisc 165 SEV
4108200	Run capacitor 32µF	1	PC	8003850 - TASKI ergodisc 165 EURO
4108200	Run capacitor 32µF	1	PC	8003860 - TASKI ergodisc 400 UK
4108200	Run capacitor 32µF	1	PC	8003880 - TASKI ergodisc 400 SEV
4108200	Run capacitor 32µF	1	PC	8003890 - TASKI ergodisc 400 EURO
4108200	Run capacitor 32µF	1	PC	8003990 - TASKI ergodisc duo UK
4108200	Run capacitor 32µF	1	PC	8004010 - TASKI ergodisc duo SEV
4108200	Run capacitor 32µF	1	PC	8004020 - TASKI ergodisc duo EURO
4108200	Run capacitor 32µF	1	PC	8004040 - TASKI ergodisc 438 UK
4108200	Run capacitor 32µF	1	PC	8004410 - TASKI ergodisc 165 KSA
4108190	Run capacitor 20µF	1	PC	7517950 - TASKI ergodisc

Drive part/2

Article no.	Description	Quantity	Unit	used for
				200 CN
4108190	Run capacitor 20µF	1	PC	8003780 - TASKI ergodisc 200 UK
4108190	Run capacitor 20µF	1	PC	8003800 - TASKI ergodisc 200 SEV
4108190	Run capacitor 20µF	1	PC	8003810 - TASKI ergodisc 200 EURO
4108190	Run capacitor 20µF	1	PC	8004030 - TASKI ergodisc 238 UK
4123187	Run capacitor 50µF	1	PC	8005000 - TASKI ergodisc 165 JP 50Hz
4117820	Relay 230V 50-60Hz	1	PC	220-240V
4117480	Relay 120V 50-60Hz	1	PC	100-120V
4126796	Capacitor plate	1	PC	
4027410	Waved washer 13,2/18,8x0,2	2	PC	
4110010	Axle 12,7x368	1	PC	
4110000	Grommet 12,5	2	PC	
4111200	Quick nut 4,2	4	PC	
4090280	Cover	2	PC	
4111460	Retaining washer 12,7	2	PC	
4122530	Wheel 180/44	2	PC	
4007380	Washer 14/26x0,5	4	PC	
4110450	Washer 7/20x1	7	PC	
4109990	Screw delta PT Torx 60x25	4	PC	
4110050	Pressure spring	1	PC	
4110310	Pressure spring	1	PC	
4057260	Hose fabric reinforced 10/16	0,048	M	
4057260	Hose fabric reinforced 10/16	0,036	M	
4109880	Flanged bush spec	1	PC	
4052720	Socket head cap screw M8x35	1	PC	
4111350	Fan blade	1	PC	
4108800	Motor 230V 50Hz 1110W 7A	1	PC	7517949 - TASKI ergodisc 165 CN
4108800	Motor 230V 50Hz 1110W	1	PC	8003820 - TASKI ergodisc

Drive part/2

Article no.	Description	Quantity	Unit	used for
	7A			165 UK
4108800	Motor 230V 50Hz 1110W 7A	1	PC	8003840 - TASKI ergodisc 165 SEV
4108800	Motor 230V 50Hz 1110W 7A	1	PC	8003850 - TASKI ergodisc 165 EURO
4108780	Motor 230V 50Hz 1100W 7A	1	PC	8003860 - TASKI ergodisc 400 UK
4108780	Motor 230V 50Hz 1100W 7A	1	PC	8003880 - TASKI ergodisc 400 SEV
4108780	Motor 230V 50Hz 1100W 7A	1	PC	8003890 - TASKI ergodisc 400 EURO
4108780	Motor 230V 50Hz 1100W 7A	1	PC	8004040 - TASKI ergodisc 438 UK
4108820	Motor 120V 60Hz 1110W 14,5A	1	PC	7510804 - TASKI ergodisc 200 NA
4108820	Motor 120V 60Hz 1110W 14,5A	1	PC	8003790 - TASKI ergodisc 175 NA
4108790	Motor 120V 60Hz 1110W 14,5A	1	PC	8003830 - TASKI ergodisc 300 NA
4110340	Motor 230-240V 50Hz 1100W 7,8A	1	PC	7517951 - TASKI ergodisc duo CN
4110340	Motor 230-240V 50Hz 1100W 7,8A	1	PC	8003990 - TASKI ergodisc duo UK
4110340	Motor 230-240V 50Hz 1100W 7,8A	1	PC	8004010 - TASKI ergodisc duo SEV
4110340	Motor 230-240V 50Hz 1100W 7,8A	1	PC	8004020 - TASKI ergodisc duo EURO
4108810	Motor 230V 50Hz 800W 5,2A	1	PC	7517950 - TASKI ergodisc 200 CN
4108810	Motor 230V 50Hz 800W 5,2A	1	PC	8003780 - TASKI ergodisc 200 UK
4108810	Motor 230V 50Hz 800W 5,2A	1	PC	8003800 - TASKI ergodisc 200 SEV
4108810	Motor 230V 50Hz 800W 5,2A	1	PC	8003810 - TASKI ergodisc 200 EURO
4108810	Motor 230V 50Hz 800W 5,2A	1	PC	8004030 - TASKI ergodisc 238 UK
4118000	Motor 220V 60Hz 1100W 7A	1	PC	7521877 - TASKI ergodisc 165 EURO
4118000	Motor 220V 60Hz 1100W 7A	1	PC	8004410 - TASKI ergodisc 165 KSA
4126431	Motor 100-110V 60Hz 1100W 18A	1	PC	8004760 - TASKI ergodisc 165 JP 60Hz

Drive part/2

Article no.	Description	Quantity	Unit	used for
4122524	Motor 100-110V 50Hz 1100W 18A	1	PC	8005000 - TASKI ergodisc 165 JP 50Hz
4109620	Lever	1	PC	
4109870	Flanged bush 8,1/17/24x32,2	1	PC	
4109640	Roll 48 compl	1	PC	
4110070	Washer 8,4/25x2	1	PC	
4028060	Socket head cap screw M8x50/28	1	PC	
4108690	Protecting ring	1	PC	
4108700	Motor cover	1	PC	
4108720	Motor hood	1	PC	7510804 - TASKI ergodisc 200 NA
4108720	Motor hood	1	PC	7517949 - TASKI ergodisc 165 CN
4108720	Motor hood	1	PC	7521877 - TASKI ergodisc 165 EURO
4108720	Motor hood	1	PC	8003790 - TASKI ergodisc 175 NA
4108720	Motor hood	1	PC	8003820 - TASKI ergodisc 165 UK
4108720	Motor hood	1	PC	8003830 - TASKI ergodisc 300 NA
4108720	Motor hood	1	PC	8003840 - TASKI ergodisc 165 SEV
4108720	Motor hood	1	PC	8003850 - TASKI ergodisc 165 EURO
4108720	Motor hood	1	PC	8003860 - TASKI ergodisc 400 UK
4108720	Motor hood	1	PC	8003880 - TASKI ergodisc 400 SEV
4108720	Motor hood	1	PC	8003890 - TASKI ergodisc 400 EURO
4108720	Motor hood	1	PC	8004040 - TASKI ergodisc 438 UK
4108720	Motor hood	1	PC	8004410 - TASKI ergodisc 165 KSA
4108720	Motor hood	1	PC	8004760 - TASKI ergodisc 165 JP 60Hz
4108720	Motor hood	1	PC	8005000 - TASKI ergodisc 165 JP 50Hz

Drive part/2


Article no.	Description	Quantity	Unit	used for
4108730	Motor hood	1	PC	7517950 - TASKI ergodisc 200 CN
4108730	Motor hood	1	PC	8003780 - TASKI ergodisc 200 UK
4108730	Motor hood	1	PC	8003800 - TASKI ergodisc 200 SEV
4108730	Motor hood	1	PC	8003810 - TASKI ergodisc 200 EURO
4108730	Motor hood	1	PC	8004030 - TASKI ergodisc 238 UK
4108710	Motor hood	1	PC	Mod Duo
4110040	Support	1	PC	
4062420	Screw delta PT Torx 30x16	3	PC	
4121969	Flat connectior 6,3-2,5	5	PC	
4121970	Female plate clip housing 3-way	5	PC	100-120V
4121971	Female plate clip housing 2-way	5	PC	
4122495	Flat connector housing 3-ways	5	PC	
4121972	Flat connector housing 2-ways	5	PC	
4083230	Female plate clip 6,3-1	5	PC	
4109990	Screw delta PT Torx 60x25	4	PC	
4109610	Cover	1	PC	Option
4122099	Washer 18/30x0,3	1	PC	
4031670	Cheese head screw M5x10	1	PC	
4007660	Serrated lock washer 5,1	1	PC	
4015720	Screw for plastic KA40x14	2	PC	
4007480	Washer 4,3/12x1	1	PC	
4130402	Electric panel 220-240V 50-60Hz	1	PC	7517950 - TASKI ergodisc 200 CN
4130402	Electric panel 220-240V 50-60Hz	1	PC	8003780 - TASKI ergodisc 200 UK
4130402	Electric panel 220-240V 50-60Hz	1	PC	8003800 - TASKI ergodisc 200 SEV
4130402	Electric panel 220-240V 50-60Hz	1	PC	8003810 - TASKI ergodisc 200 EURO

Drive part/2


Article no.	Description	Quantity	Unit	used for
4130402	Electric panel 220-240V 50-60Hz	1	PC	8004030 - TASKI ergodisc 238 UK
4130403	Electric panel 220-240V 50-60Hz	1	PC	7517949 - TASKI ergodisc 165 CN
4130403	Electric panel 220-240V 50-60Hz	1	PC	7521877 - TASKI ergodisc 165 EURO
4130403	Electric panel 220-240V 50-60Hz	1	PC	8003820 - TASKI ergodisc 165 UK
4130403	Electric panel 220-240V 50-60Hz	1	PC	8003840 - TASKI ergodisc 165 SEV
4130403	Electric panel 220-240V 50-60Hz	1	PC	8003850 - TASKI ergodisc 165 EURO
4130403	Electric panel 220-240V 50-60Hz	1	PC	8004410 - TASKI ergodisc 165 KSA
4130404	Electric panel 220-240V 50-60Hz	1	PC	8003860 - TASKI ergodisc 400 UK
4130404	Electric panel 220-240V 50-60Hz	1	PC	8003880 - TASKI ergodisc 400 SEV
4130404	Electric panel 220-240V 50-60Hz	1	PC	8003890 - TASKI ergodisc 400 EURO
4130404	Electric panel 220-240V 50-60Hz	1	PC	8004040 - TASKI ergodisc 438 UK
4130405	Electric panel 220-240V 50-60Hz	1	PC	7517951 - TASKI ergodisc duo CN
4130405	Electric panel 220-240V 50-60Hz	1	PC	8003990 - TASKI ergodisc duo UK
4130405	Electric panel 220-240V 50-60Hz	1	PC	8004010 - TASKI ergodisc duo SEV
4130405	Electric panel 220-240V 50-60Hz	1	PC	8004020 - TASKI ergodisc duo EURO
4126974	Electric panel 120V 60Hz	1	PC	7510804 - TASKI ergodisc 200 NA
4126974	Electric panel 120V 60Hz	1	PC	7523241 - TASKI ergodisc 200 BR 127V
4126974	Electric panel 120V 60Hz	1	PC	8003790 - TASKI ergodisc 175 NA
4126974	Electric panel 120V 60Hz	1	PC	8003830 - TASKI ergodisc 300 NA
4023260	Cable tie 200	1	PC	
4110410	Assembly tool belt	1	PC	
4039680	Lubricant synsetral 53B	1	PC	

Drive part/2

Article no.	Description	Quantity	Unit	used for
	1000gr			




Ergänzung, supplement
Gruppe, group(e) 04




Dispensing unit mechnical

Article no.	Description	Quantity	Unit	used for
4110190	Housing	1	PC	
4122315	Thread form screw torx M5x25	2	PC	
4110230	Disc	1	PC	
4114430	Counters. head screw 4x12	1	PC	
4110220	Trigger	1	PC	
4110250	Bottle 0,5 L	1	PC	
4110260	Tapped cap	1	PC	
4071680	Screw for plastic KA50x12	1	PC	
4007450	Washer 5,3/20x1,5	1	PC	
4110200	Torsion spring	1	PC	
4110210	Lever	1	PC	
4119750	Nozzle	1	PC	
4119760	Nozzle 80°	1	PC	
4110170	Holder set	1	PC	
4122587	Spray lance compl	1	PC	
4049370	Hose 2/4 PA	0,5	M	
4114400	Clamp	1	PC	
4110270	Bush spec	1	PC	
4114420	Screw for plastic KA40x35	1	PC	
4008940	O-ring 10,82x1,78	1	PC	
4110240	Bowden cable	1	PC	
4008500	Ball bearing 6203 2RS	1	PC	
4044550	Ball bearing 6204 2RS	1	PC	230V; D 19,7
4022420	Ball bearing 6005 2RS	1	PC	120V; D 24,5
4123157	Quick connector 4	1	PC	



Einbaulage Riemen
position courroie
belt position




Dispensing unit electrical

Article no.	Description	Quantity	Unit	used for
4110130	Holder compl	1	PC	
4082610	Screw for plastic KA50x16	2	PC	
4055370	Hose 4/7 silikone	0,04	M	
4083690	Quick connector 4-R1/8"	1	PC	
4132663	Pump 230V 50Hz 48W	1	PC	8504360 - Dispensing unit electrical 230V ergod.
4110140	Pump 220-240V 50Hz 32W compl	1	PC	8504360 - Dispensing unit electrical 230V ergod.
4105860	Pump 110-120V 60Hz 32W compl	1	PC	8504630 - Dispensing unit electrical 120V ergod.
4132663	Pump 230V 50Hz 48W	1	PC	8003840 - TASKI ergodisc 165 SEV
4132663	Pump 230V 50Hz 48W	1	PC	8004010 - TASKI ergodisc duo SEV
4105860	Pump 110-120V 60Hz 32W compl	1	PC	7510804 - TASKI ergodisc 200 NA
4105860	Pump 110-120V 60Hz 32W compl	1	PC	8003830 - TASKI ergodisc 300 NA
4000900	Bottle 0,75 L	1	PC	
4115920	Tapped cap	1	PC	
4122265	Tapped cap	1	PC	
4110280	Filter	1	PC	
4122315	Thread form screw torx M5x25	2	PC	
4110150	Holder	1	PC	
4110290	Bush 5,2/10x11	2	PC	
4122625	Hose 5/9 PVC	0,7	M	
4049370	Hose 2/4 PA	1,15	M	
4049370	Hose 2/4 PA	0,05	M	
4110170	Holder set	1	PC	
4119750	Nozzle	1	PC	
4119760	Nozzle 80°	1	PC	
4022360	Clamp	2	PC	
4109370	Screw for plastic KA50x25	2	PC	
4060330	Washer 5,3/15x1,2	2	PC	
4008940	O-ring 10,82x1,78	1	PC	
4101680	Hose clamp 9,5-10,5	1	PC	

Dispensing unit electrical

Article no.	Description	Quantity	Unit	used for
4065440	Cable tie 100	1	PC	
4123157	Quick connector 4	1	PC	


Electrical diagram 230V/50Hz



ergodisc /5

07

TASKI ergodisc
120V/60Hz



BN	BRAUN	BRUN	BROWN
BU	BLAU	BLEU	BLUE
RD	ROT	ROUGE	RED
BK	SCHWARZ	NOIR	BLACK
VT	VIOLETT	VIOLET	VIOLET
GY	GRAU	GRISE	GREY
GN/YE	GRÜN/GELB	VERT/JAUNE	GREEN/YELLOW

ergodisc /5

08

Electrical diagram 120V/60Hz