



CLEANMAX PARTS BOOK

**ZOOM 2nd GENERATION MODELS
ZM-500 ZM-700**






HANDLE AND BODY

Cleanmax Model ZM-500 ZM-700


KEY	PART NUMBER	DESCRIPTION
1	C220-3514	Handle Grip Assembly
2	A732-8314	Screw Hi Lo #8 x 5/8
3	B352-6900	Cord Retainer Hook
4	A328-1700	Two Speed Switch
5	A732-8414	Screw Hi Lo #10 32 x 1.625
6	B017-2500	Nylon Washer
7	B220-3400	Handle Tube
8	B220-3114	Handle Back Cover
9	A432-0705	Screw #10 32 x 1.625
10	A430-0405	Washer
11	B220-3314	Swivel Cord Hook
12	B430-0200	Upper Cord Hook Spring
13	B220-1114	Neck Coupling Back
14	A434-3514	Wire Harness
15	A432-0805	Hex Nut #10-32
16	B220-1014	Neck Coupling Front
17	B220-3014C	Handle Duct
18	D484-2282	Bag Mount Assembly
19	B220-3900	Bag Mount Seal
20	B220-3814	Bag Mount
21	B434-2282	Bag Mount Hinge
22	B434-3400	Bag Collar Spring
23	B220-6800	Hard Shell Bag
24	B220-5382C	HEPA Bag (Bulk Single)
	CLH-6	HEPA Bag (6 pack)
	B211-8800	Paper Bag (Bulk Single)
25	D434-3814	Pigtail Cord Assembly
26	B388-5900	Polyurethane Handle Spacer
27	B220-6214	Carry Handle
28	CMPS-EXT30	Extension Cord 30'



NOZZLE ASSEMBLY

Cleanmax Model ZM-500 ZM-700

KEY	PART NUMBER	DESCRIPTION	KEY	PART NUMBER	DESCRIPTION
1	B220-24ZM	Nozzle Cover (ZM-500)	26	B015-3000B	Squeegee
	D220-24ZM	Nozzle Cover (ZM-700)	27	B220-0414	Baseplate Cover Screw
2	B220-2600	Clean Furniture Guard	28	B370-1700B	Bottom Plate Axle
3	B018-0414	Lens Cover	29	B370-1843	Bottom Plate Wheels
4	D220-4000	Motor Assembly Flat Belt (ZM-500)	30	D012-2800	Wood Agitator (ZM-500)
	D220-4100	Motor Assembly Lifetime Belt (ZM-700)		D013-0500	Metal Agitator for Lifetime Belt (ZM-700)
5	B220-4314	Motor Fan	31	B220-4014	Scroll Housing Right
6	B220-4414	Pivot Bushing	32	B220-4114	Scroll Housing Left Fan Cover
7	B480-4514	Motor Inlet Seal	33	B016-1914	Hall Sensor Plug (ZM-500)
8	CMZM-B2	Flat Belt 2 pack (ZM-500)	34	A018-1414	Breaker Plug (ZM-700)
	B014-0814B	Flat Belt Bulk Single (ZM-500)	35	B034-0100	Strain Relief Washer
	B014-1200	Lifetime Belt (ZM-700)	36	A732-2500	Combo Screw M4 X 12
9	D220-0114	Basetray Assembly	37	A432-0605	Hex Nut 1/4-20
10	B220-0900	Spring	38	A733-2200	Washer Over Fan
11	B220-0714	Pedal	39	A733-3300	Washer Under Fan
12	B220-0800	Pedal Pivot	40	B220-4500	Felt Seal
13	D220-0714	Pedal Assembly	41	A732-3000	E Clip .250 (ZM-500)
14	54.136	Axle Clamp	42	A028-0114B	5 Amp Circuit Breaker (ZM-500)
15	B220-0214	Inlet Duct Cover	43	B333-1100B	Ground Wire
16	D375-1400	Hall Sensor Assembly (ZM-700)			
17	A018-1000	Dowel Pin (ZM-700)			
18	B317-0000K	PC Board (ZM-500)			
	B317-1000BK	PC Board for Hall Sensor (ZM-700)			
19	B010-2800C	Large Wheel Axle			
20	C220-0531C	Rear Wheel			
21	D010-2631	Front Wheel Assembly			
22	A732-8414	Screw Hi Lo #8 X 7/16"			
23	A732-8314	Screw Hi Lo #8 X 5/8"			
24	D220-0414	Baseplate Assembly (Standard)			
	D220-1414	Soft Carpet Baseplate Assembly (Optional)			
25	Order #24	Baseplate Cover			



KEY	PART NUMBER	DESCRIPTION
1	A375-0100	1/4 - 28 Locking Hex Nut
2	B013-1600	Metal End Cap
3	A733-1810	Screw Pulley End 80mm
4	B475-1900	Retainer Ring
5	B375-3900	Felt Seal
6	A375-0200	Bearing
7	B013-1400	Lifetime Belt Pulley
8	B013-1000	Short Brush Strip Nylon (Standard)
	B013-0301B	Short Brush Strip White (Softer)
	B013-0400	Short Brush Strip Natural (Softest)
9	B475-0400B	Long Brush Strip Nylon (Standard)
	B013-0401B	Long Brush Strip White (Softer)
	B013-0300	Long Brush Strip Natural (Softest)
10	B013-1500	Bearing Holder With Edge Brushes
11	A733-1800	Screw Non-Pulley End 40mm
12	D013-0500	Steel Agitator Assembly for Lifetime Belt