


NOZZLE ASSEMBLY

TITAN Model T500



NOZZLE ASSEMBLY**TITAN Model T500**

KEY	PART NUMBER	DESCRIPTION
1	B220-2041	Nozzle Cover
2	B220-2214	Furniture Guard
3	B220-2115	Lens
4	A732-3000	E Clip
5	B223-2814C	Motor Support Boss
6	Order D223-2100	14,000 RPM Motor
7	B223-0114	Motor Housing
8	A733-5000	Screw M5 X 6mm Socket
9	B220-4414	Pivot Bushing
10	B220-4500	Felt Pivot Seal
11	B220-4014	Scroll Housing Right
12	A733-3300	Washer (Behind Fan)
13	B220-4314	Motor Fan
14	A733-2200	Washer
15	A432-0605	Hex Nut
16	B220-4114	Scroll Housing Left
17	A732-8314	Pan Head Hi Lo Screw #8 X 5/8
18	B480-4514	Motor Inlet Seal
19	D223-2100	Motor Assembly
20	B220-0214	Inlet Duct Cover
21	D220-0114	Basetray Assembly
22	B016-1914	Basetray Plug
23	B220-0900	Upright Stop Spring
24	54.136	Rear Axle Clamp
25	D220-0714	Upright Stop Pedal Assembly
26	B220-0714	Upright Stop Pedal
27	B220-0800	Upright Stop Pedal Pivot
28	A018-1414	Hole Plug
29	B317-1150K	LED PC Board Removable Battery
30	B010-2800C	Large Wheel Axle
31	C220-0531C	Rear Wheel
32	B010-0001E	Front Wheel Axle
33	C010-2714B	Front Wheel W/Bushing

KEY	PART NUMBER	DESCRIPTION
34	D220-0414	Baseplate Assembly
35	Order #34	Baseplate
36	B015-3000B	Squeegee
37	B220-0414	Baseplate Cover Screw
38	B370-1700B	Baseplate Wheel Axle
39	B370-1843	Baseplate Wheel
40	B014-0814B	Belt (Bulk Single)
41	D223-1700	Wood Agitator with White Bristles
42	A732-2500	Combination Screw M4 X 12 ULW
43	B034-0100	Strain Relief Washer
44	B223-6000	Harness Removable Battery