

AUTO-FILL (KC-500-ADAF)**OPERATION:**

- Attach a 3/4" garden hose to the Auto-Fill Hose Connector (7), and connect the other end of the hose to your water source.
- Make sure the float that hangs from the auto fill valve into the tank is free of obstruction and can move freely.
- Turn on the water supply. **NOTE:** Do not turn the water pressure on high; just turn the water on.
- The auto-fill float will automatically shut-off the flow of incoming water when the tank is nearly full, and it will allow the valve to open again once the water level has dropped to a predetermined level.

AUTO-DUMP (KC-500-ADAF)**OPERATION:**

Before each use: Always use a clean pre-filter bag when operating the machine. If necessary, unscrew the stainless steel filter at the bottom of the recovery tank and clean it. Also make sure the ball float in the recovery tank is clean.

- Attach a 3/4" garden hose to the Dump Hose Connection (14) on the dump pump on the back of the base of the machine.
- Run the other end of the hose into a drain.
- Turn ON the dump pump switch (25).
- **NOTE:** The dump pump is 'self-priming.' You should see water start to flow within 30 seconds of the pump turning on. If water does not begin to flow, check the filter to see if it is plugged with debris.

After each job: Run clear water through the dump pump to wash out any chemical residue. Remove and clean both the Pre-Filter Bag (22) and the Pump Inlet Filter (21). Reinstall the filter once it is clean. Clean and empty the recovery tank.

**DANGER!**

Do NOT use solvents, or any chemicals that may be flammable, explosive or combustible.

**CAUTION!**

Always use a defoamer in the recovery tank to prevent water or foam from entering the vacuum motor.

**DANGER!**

Always unplug the King Cobra from the electrical outlet(s) before cleaning or maintaining. Certain internal components are electrically live, even with switches in their OFF position.