

Cleaning Upholstery

This is done in the same way as carpet cleaning except using the upholstery tool in place of the wand assembly. Cleaning is achieved using a gentle dragging motion of the upholstery tool over the material.

- An inconspicuous area of the item to be cleaned should always be tested for color fastness prior to cleaning. Should doubt exist as to the suitability of the fabric for wet cleaning, the chemical manufacturer should be consulted for advice.
- Loose cushions should be removed and cleaned separately.
- Care should be taken to avoid over-wetting the fabric.

When Cleaning is Finished

Draining and Cleaning

- Before removing the spray hose, pressure in the system must be released. With the pump switched off, hold the spray nozzle over the removable recovery tank and squeeze the spray trigger until the remaining solution has been released. The spray hose can now be disconnected.
- After use, check that both solution tanks are empty.
 - Empty the solution tank and rinse.
 - Empty the recovery tank and rinse clean.
 - Rinse both tanks out with clean water before storing the machine.
 - Clean nozzles and hoses.

Storage

- Always unplug, empty, wipe down and dry the machine after use.
- Wrap supply cord around the handle of the machine ensuring that the plug is not trailing on the floor. Store the machine in a dry indoor area only.

Maintenance

WARNING – Before undertaking maintenance operations or adjustments, switch off machine and unplug from the electricity supply.

The machine requires minimum maintenance apart from the following checks by the operator.

- Supply cord – Regularly inspect sheath, plug and cord anchorage for damage or loose connection.
- Solution tank – Check filters are clean and undamaged. A damaged or missing filter must be replaced or damage to pump head and spray jet may occur.
- Vacuum filter – Check the vacuum filter is cleaned and replaced as appropriate.
- Vacuum head – Check and remove debris or lint build-up from the head.
- Spray jet – Check jet for blockage and full spray pattern. Blow through jet to clean. Do not use a pin, as this could damage the jet.

IMPORTANT – All other servicing and repairs should only be performed by a Tornado engineer or an Authorized Service Agent.

IMPORTANT – Should the machine fail to operate please refer to the fault diagnosis section in the back of the instruction manual. If the problem/remedy is not listed, please contact Tornado Customer Service Department.

After Sales Service

Should you require after sales service, please contact the supplier from whom you purchased the machine, who will arrange service. Repairs and servicing for Tornado products should only be performed by trained staff. Improper repairs can cause considerable dangers to the user.