



TASKI® swingo® 755 B



Unplug cable of battery charger.



Connect the Battery cut-off switch.



Fill solution tank with clean water.

COLD WATER ONLY



Mix the proper amount of cleaning chemical into the clean water tank.



Mount squeegee:
Position the pockets of the squeegee exactly under the squeegee holder and push holder down.



Position the pads or brushes carefully under lifted brush unit.



Turn the machine on.



Lower the scrub deck onto the brush with foot pedal.



Start vacuum motor and solution supply (press orange buttons).



Adjust solution flow (depending on model - with buttons on dashboard or with lever).



Lower the squeegee with squeegee lever.



Clean the floor.



Turn off solution - Run machine with squeegee down and vac on until water is recovered.



Remove tank from machine by pulling the hook. Unlock and remove filter housing. Empty tank and rinse both tanks.



Remove the vacuum unit (filter <u>and</u> float) with a rotation of the yellow filter in counter-clockwise direction.



Clean the vacuum filter unit under running water.



Clean solution filter.



Remove brushes or pads, clean and allow to air dry.



Remove and clean squeegee.



Wipe machine with moist cloth.



Remove the Battery cut-off switch and connect the charger.



Plug in the cable for the Battery charger. NOTE: ALWAYS Plug in Machine when not in use!



Flip dosing aid.



Store machine with partially open lid (lid rests on dosing aid) for ventilation.

ATTENTION! Do not use the machine before you have read and understood the operating instructions!

Questions: 1-800-558-2332

www.diversey.com