

56265191 HANDLE PIVOT KIT

AquaClean™ 18FLX
Klenzor™ 18MPH

CONTENTS OF KIT

ITEM	PART NO.	QTY	DESCRIPTION
	56040911	1	Instruction Sheet
1	56001841	2	Scr, Soc Set Loc 1/4-20 x .25
2	56002098	2	Wsh, Flt SAE 1/4
3	56003284	2	Nut, Hex Nyl Loc 1/4-28
4	56265241	2	Pivot, Handle Adjustment
5	56265242	2	Pivot Pin

INSTALLATION INSTRUCTIONS

WARNING!

DISCONNECT POWER BEFORE SERVICING.

- 1** See **Figure 1**. Remove the (9) Screws **(A)** from the Handle Back Cover **(B)**.
- 2** Pull the Handle Back Cover **(B)** away from the Front Cover and remove the (2) Set Screws **(C)**. The Handle Release **(D)** and Back Cover **(B)** can now be removed from the machine. **NOTE:** Make sure the Spray Button **(E)** does not get misplaced.
- 3** Measure the distance from the top of the Nut **(F)** to the top of the Wire Rope **(G)** on each side. Note these measurements for re-assembly.
- 4** Remove the (2) Nuts **(F)** and remove the Pivot Assemblies **(H)** from the machine.
- 5** Assemble Items **(2, 3, 4 & 5)** onto the top of each Wire Rope **(G)** as shown. Tighten the Nuts **(3)** until the distance from the top of the Nuts **(3)** to the top of the Wire Ropes **(G)** is the same as it was prior to disassembly.
- 6** Follow steps 1 & 2 in reverse order to complete assembly. **NOTE:** Use the new Set Screws **(1)** included with the kit.

FIGURE 1

