

56315958 HANDLE LOWERING KIT

Advance 34RST Models: ALL

CONTENTS OF KIT

ITEM	PART NO.	QTY	DESCRIPTION
	56040975	1	Instruction Sheet
1	56315576	2	Handle Mounting Plate
2	56396199	1	Clamp, Plastic
3	56002035	4	Screw, Hex Head 5/16-18 x .62
4	56002701	4	Nut, Hex Nylon Lock 5/16

INSTALLATION INSTRUCTIONS

- 1 Disconnect the main battery cable.
- 2 Pull the recovery tank drain hose out of its retention clamps.
- 3 Remove and save the existing (4) handle mounting screws and washers. Be careful to support the handle so it does not place a load or stress on the handle wiring harness. The handle can be hung on the squeegee lift lever.
- 4 Remove the (4) mounting screws from the rear electrical panel, and remove the panel.
- 5 Replace the existing drain hose retention clamp with the new Clamp (2) 56396199 supplied in the kit.
- 6 Reinstall the rear electrical panel, using the (4) existing mounting screws.
- 7 Attach each of the 56315576 handle mounting plates (1) onto the left and right portions of the solution tank, positioning each over the threaded inserts where the handle was originally mounted. Each plate should be oriented so the rear set of holes is located lower than the front set of holes. Use the four 56002035 Screws (3) to mount the plates. **See Figure 1.**
- 8 Reinstall the handle onto the handle mounting plates. Use the (4) existing screws and flat washers, orienting them through the handle, then through the plate, and tighten with the four 56002701 Nuts (4) supplied in the kit. **See Figure 2.**
- 9 Place the recovery tank drain back into its retention clamps.
- 10 Reconnect the main battery cable.
- 11 Test the machine for proper operation.

FIGURE 2

FIGURE 1

