

Gen2 Shelf Scanner -- Soft & Hard Reboot

Description

How to properly perform a Gen2 shelf scanner robot reboot (BCM/SPA)

Applies To

Gen2 Shelf Scanners

Instructions

When performing a hard reboot of a robot with a Shelf Scanner attached, perform the following steps:

1. Power off the scrubber with the keyswitch
2. Lift the seat and check the status of the power button
 - Flashing - SPA is powered on and is awake
 - Solid - SPA is in sleep mode. (Power is on)
 - Off - SPA is powered off
3. If under seat button is on solid or flashing, press the under seat power button for 3 seconds to power it off.
 - Do not proceed until the under seat button is off.
4. Once SPA is off, disconnect the batteries.
5. Wait a full minute
6. Connect the batteries.
7. Turn the key on to power the BCM
8. Press the under seat button for 3 seconds to power on the SPA.
9. The under-seat button LED should initially turn on steady (green) then start flashing when the SPA is up and awake.

